Climbup® Insect Inceptors Directions for Use

1. **Installation:**
   - When handling the devices only touch the outer wall of the device.
   - Place Climbup® devices under each leg of the furniture where people sleep or rest (beds, sofas, armchairs etc.) so that the leg rests within the center well of the device (See fig #1). In order to avoid injury, be sure to use proper lifting techniques and do not lift any objects that too heavy for you to lift properly.
   - Eliminate all other pathways for bugs to access furniture. "Bridges" for bed bugs to travel on will be created if the furniture is touching a wall or another object, or anything is hanging off of the furniture onto the floor. For example, all sheets and comforters should always be tucked in, and no items should be allowed hang down and touch the floor. All electric cords should be disconnected between bed and wall. Any items on the furniture that are touching the floor or wall will provide bed bugs a "bridge" to access the furniture and bypass the Climbup® devices. It is important that the only avenue onto the furniture is via the legs that are contained within the Climbup® insect interceptor.
   - The monitors should be left in place for a minimum of 21 days to provide the best opportunity to intercept bed bugs as they move around your home. Ideally, the monitors should be left in place indefinitely so that they are continually monitoring for bed bugs.

2. **Once installed:**
   - Continue to keep furniture pulled away from the wall and do not allow any objects on furniture to contact the floor or wall.
   - Periodically observe the Climbup® devices for bed bugs. Bed bugs approaching bed from room will be in the outer pitfall ring. Bed bugs climbing down from bed will be found in center well. Remove bed bugs from device by wiping out with cotton ball and immediately place cotton ball in sealed plastic bag for disposal.
   - Check the Climbup® devices to make sure that they have not become compromised in any way.
     Examples include but are not limited to:
     a. Checking for the presence of debris or other items present in the wells that may provide a method for the bugs to escape the wells.
     b. Checking to see if it has been covered in dust.
     **** NOTE: If the any of the Climbup® devices are compromised in way, debris will need to be removed or the device discarded. It is important to exercise care when checking or handling Climbup® devices after they have been installed as live bugs may be in, on, or around the devices.**

3. **Handling Climbup® Insect Interceptors After Installation:**
   It may become necessary to handle Climbup® devices from time to time to remove debris and/or bugs or to discard the devices. Care should be taken when handling Climbup® insect interceptors after installation as live bugs may be in, on, or around the devices. When handling devices be sure to:
   - Remove device carefully from beneath the legs of the furniture
   - Wash device in soapy water to fully immerse all of the bugs
   - Empty soapy water containing bugs into the toilet. The trap may need to be rinsed more than once to remove all the bugs. After emptying soapy water and bugs into the toilet the toilet should be flushed. Physical debris should not be flushed down toilets but can be placed into a sealed bag for disposal in an outdoor trash receptacle.
   - Fully dry the outer wall as well as the inner walls and wells of the Climbup® with a paper towel. The paper towels should be immediately sealed in a plastic bag and discarded in an outdoor trash receptacle.

4. **Discarding Climbup® Insect Interceptors After Installation:**
   Care should be exercised when discarding Climbup® devices to avoid contact with live bugs that are on, in or around the devices.
   When discarding devices be sure to:
   - Prior to removing the devices, you should have plastic bags available to place the traps in after removing them from beneath the legs of the furniture. It is important that the bags do not have any rips, tears or holes. You should have the bags with you so the devices can be immediately placed in the bags once they are removed from under the legs of the furniture.
   - Remove Climbup® carefully from beneath the legs of the furniture and immediately place into a sealed plastic bag.
   - Wash device in soapy water to remove all bugs. The soapy water can be dumped into a toilet and flushed. The Climbup® devices are made of recyclable plastic and once cleaned can be disposed of in a recycling bin that accepts high density polyethylene (HDPE= #2 recycling symbol). If device is not washed, discard in sealed plastic bag in outdoor receptacle.

Precautionary Statements

- Climbup® insect interceptors are not intended to be a control measure for bed bugs.
- Climbup® insect interceptors may not be able to be used with certain beds or couches.
- Climbup® insect interceptors manufactured of polypropylene molded as a high mirror finish since 2014 do not need talcum powder to be slick enough to catch common bed bugs if inner surface is kept clean.
- If humans or pets are not sleeping on bed or couch, bed bugs will not be attracted into device.
- Live bugs may be present on, in, or around Climbup® insect interceptors.

For more information, visit www.jteaton.com

J.T. Eaton & Co., Inc.
1393 East Highland Road
Twinsburg, OH 44236



FIG. 1. **Climbup® Insect Interceptor**

The manufacturer of the Climbup® insect interceptor is not responsible for any injury, disease or illness caused, or allegedly caused by bites, stings or contamination of bed bugs or any other insects.

EPA EST. NO. 56-OH-002
Climbup® is a registered trademark of Susan McKnight, Inc.

Instrucciones para el uso de los interceptores de insectos Climbup®

1. **Para la instalación en habitaciones ocupadas por personas**
   - Cuando maneje los dispositivos solo toque la pared exterior del dispositivo.
   - Coloque los aparatos Climbup® debajo de cada pata del mueble donde se duerme o se descansa (camas, sofás, sillones, etc.) para que la pata descanse dentro del centro del pozo del aparato (véase figura #1). Para evitar cualquier lesión, utilize técnicas apropiadas para levantar el mueble. No levante ningún objeto que sea demasiado pesado para que Usted lo pueda levantar apropiadamente.
   - Elimine cualquier otra vía de acceso a los muebles para los insectos. Se pueden crear "puentes" para los insectos de cama si el mueble está tocando una pared u otro objeto ó si hay algo que está colgado del mueble y tocando el piso. Por ejemplo, las sábanas y los edredones deben estar metidos entre el colchón y el colchón de muelles y no se debe permitir que cuelguen y toquen el piso. Los cordones eléctricos no deben conectarse entre la cama y la pared. Cualquier artículo o mueble que toque el piso o la pared puede ofrecer un "puente" y acceso a los insectos al evitar los aparatos Climbup®. Es importante que la única vía hacia el mueble sea por las patas del mueble que estén dentro del interceptor de insectos Climbup®.
   - Los monitores se deberán mantener por un minimo de 21 dias para que haya mas oportunidad a interceptar los insectos de la cama mientras estos estén caminando dntro de su hogar. Lo ideal seria mantener los monitores indefinidamente para que continuamente estén verificados si hay insectos de cama.

2. **UNA VEZ INSTALADOS** Observe periódicamente los aparatos Climbup® para ver si hay insectos de cama. Los insectos de cama que traten de treparse a la cama estarán en el anillo exterior. Los insectos de cama que estén bajándose de la cama se encontrarán en el centro del pozo. Remueva los insectos de cama del aparato limpiándolos con un algodón y un poco de talco. Coloque inmediatamente el algodón en una bolsa plástica, selle la bolsa y bote a la basura.
   - Verifique que los aparatos Climbup® no estén dañados en ninguna manera. Por ejemplo:
     a. Verifique si hay basura o alguna otra cosa en los pozos que pueda proveer una manera para que los insectos se escapen de los pozos.
     b. Verifique si el talco dentro de los pozos se ha borrado o si está cubierto de polvo.

***NOTA: si cualquiera de los dispositivos Climbup se encuentran en peligro, se deveran eliminar los restos o se distorcionara el dispositivo es importante tener cuidado al verificar o manipular los dipositivos de climbup después de que se ha instalado, ya que los insectos vivos pueden estar en sobre o alrededor de los dispositivos.

3. Manejando los interceptores de insectos Climbup® después de la instalación:

Puede ser que necesite manejar los aparatos Climbup® de vez en cuando para remover basura, remover los insectos, o para botar los aparatos. Debe tener cuidado al manejar los interceptores de insectos Climbup® ya que pueden tener insectos vivos dentro o alrededor de los aparatos. Al manejar los aparatos asegúrese de:

- Remover con cuidado los aparatos de debajo de las patas del mueble.
- Sumergir los aparatos en agua con jabón hasta sumergir por completo todos los insectos.
- Vaciar el agua enjabonada con los nsectos en el inodoro .puede ser que tenga que njuagar mas de una vez para remover todos los insectos .despues de vaciar el agua enjabonada en el inodoro, devera vaciar en le inodoro .no debe vaciar el aparato al inodoro, sino que lo debe colocar en una bolsa plástica , sellarla y botarla en la basura fuera de la casa.

4. **Para descartar los interceptores de insectos Climbup® después de** los insectos vivos que estén dentro o alrededor de los aparatos. Al descartar los aparatos:

- Antes de remover los aparatos debe tener bolsas plásticas disponibles para colocar las trampas. Es importante que las bolsas no estén rotas ni tengan agujeros.
- Lave los aparatos en agua enjabonada para remover los insectos. El agua enjabonada se deberá vaciar en un inodoro y se deberá vaciar el inodoro. Los aparatos Climbup® están hechos con plástico reciclable y una vez estén limpios pueden descartarse en un bote de reciclaje que acepte poletilieno de alta densidad (con símbolo de reciclaje HDPE= #2). Si el aparato no está limpio, coloque en una bolsa plástica, séllela y bote en la basura fuera de la casa.


Declaraciones Preventivas

- Los interceptores de insectos Climbup® no son una medida de control para los insectos de cama.
- Puede ser que no se puedan usar los interceptores de insectos Climbup® con ciertas camas o colchones.
- Insecticidas de insectos Climbup® fabricados de poliprofeno.
- Si no hay personas o animales durmiendo en la cama, ó si no se usa la técnica de hielo seco en el pozo del centro, los aparatos no van a ejercer atracción a los insectos de cama.
- Si la habitación tiene alfombras acojinadas, puede ser que las patas del mueble rompan el pozo interior.
- Puede ser que hayan insectos vivos dentro, o alrededor del los interceptores de insectos Climbup®

Para más información visite **www.jteaton.com**

J.T. Eaton & Co., Inc.
1393 East Highland Road
Twinsburg, OH 44087

FIG. 1. **Interceptor de insectos Climbup® debajo de una pata de la cama.**



El fabricante del interceptor de insectos Climbup® no es responsable por cualquier daño, o enfermedad que sean causados por picadas, o por contaminación de insectos de cama o cualquier otro insecto.

Climbup® es una marca registrada de Susan McKnight, Inc.
EPA EST. NO. 56-OH-002